

Safety Advisory for SKLI Insulated Swivels

⚠ DANGER  **INSULATES UNDER TENSION ONLY**

Gunnebo Johnson Corporation is issuing a Safety Advisory for SKLI Insulated Swivels. This advisory pertains to a condition under which they will not insulate.

The gap shown in Figure No. 1 must be maintained in order to insulate up to 1000 V.

This gap is only maintained when the swivel is loaded (under tension).

While unloaded, this gap can reduce to an amount that will result in ZERO insulation.

This condition can occur when a sling leg becomes relaxed as a result of “bouncing” the lifted material or when over lowering the sling.

Gunnebo SKLI Swivels must always be loaded (under tension) when electrically energized to properly insulate.

Please contact Gunnebo-Johnson at
800-331-5460 for any questions.

Figure No. 1

